




The Piglet™ Bow Light System


Thank you for purchasing the all new Piglet™ Bow Light. It is smaller, lighter, brighter, and more versatile than any other bow lights.

The Piglet™ is ideal for bow hunters who want to install their favorite stabilizer for a more familiar shooting experience. The new Piglet™ bow rail mount allows the light to be positioned just under the arrow for proper target illumination with a bow, even from ground blinds. The versatility of the Piglet™ bow rail mount allows the user to easily attach a multitude of accessories.


- Piglet™ 3 Mode Light (low, medium, high)
- Light weight (2.5oz) bow rail mount
- Genuine Mathews Harmonic Damper™
- Use a bipod for ground blind hunting
- Use your favorite stabilizer
- Add an Ultra-Light laser sight for quick target acquisition without removing your existing bow sight.
- Quickly add accessories like camera mounts, fishing reels, lasers, and bipods.



The Piglet™



To place 16340 batteries in the Kill Light® Universal Charger, flip up the spring loaded contact plate in the center of the charging bay. Place the battery in the charging bay so it is held in place by the spring loaded contact plate. The charger includes A/C and 12v adapters for charging at home or on the go. The LED indicator will turn to red when charging and green when complete. It takes about one hour to charge the 16340 battery.



After the 16340 batteries are charged, place one into the Piglet™. Mount the Piglet™ into the ring mount.


The Piglet may also be powered by a single CR123A battery.

Do not use two smaller batteries in the Piglet™, this will damage light and void the warranty.




The Piglet has three brightness settings; low, medium, and high. To change between the different brightness settings, press the button half way (just enough to interrupt the power), and let up. The light will cycle between brightness modes. If you select the desired brightness setting and leave the light on for four or more seconds and turn it off. The piglet™ will remember the previous brightness setting the next time it is switched on.


The Piglet™ Rail System



Place bolt into Piglet™ Rail, and thread into the bow stabilizer receiver. Holding the Piglet™ Rail in place, tighten the bolt until secure. Be careful not to over tighten the bolt and damage the brass insert.




If the Piglet™ Rail rotates when tightening with the hex wrench, rotate the rail 30° to the left before tightening. After tightening with the hex wrench, rotate the Piglet™ Rail the rest of the way by hand.



Attach Piglet™ ring mount to the Bow Rail. Attach the wired switch to your riser or grip using the adhesive Velcro backer on the switch, or you may use the Piglet™ with the flashlight button.


The Piglet™ Rail Accessories



A traditional stabilizer may be screwed into the threaded receiver on the Piglet™ Rail for a more familiar shooting experience. This is also the proper location to add a wrist sling if desired.



Add an Ultra-Light Green or Red laser to your Piglet™ Rail for fast target acquisition.



The Piglet™ Rail is an ideal platform to add bipods, camera mounts, bow fishing tactical reel seats, sighting lasers, and many other accessories to your bow.

- If the Piglet™ starts to flash on/off, it is time to recharge the batteries. This is a sign that the batteries are running low on power.
- Your Piglet™ should run over 1 hour on the 16340 battery in the medium brightness setting. However, if you want a longer runtime, an extended runtime battery and extension tube kit is available for 4–5 hours of continuous use.
- The Piglet™ is water-resistant and not waterproof.
- Use the Piglet™ at your own risk. Elusive Wildlife Technologies, LP is not responsible for any and all injuries or damage that may occur while using the Kill Light® or charging batteries. Whenever charging any battery they should never be left unattended. Batteries can explode and should always be charged in a safe place.
- The piglet is designed to be used with regular broadheads. Double check the clearance between the broadhead and Piglet™ before use.
- If the Piglet™ will not be used for a long period of time, charge the batteries, then install battery in light and run for 10 minutes and then take battery out and store in a dry cool place. The batteries should be charged at least once every four months.
- Warning - Never look directly into light bulb when on. The LED is VERY bright and can damage your eyes.
- If you have any questions, comments or need to contact us, please send us an e-mail at info@elusivewildlife.com.