


Piglet Mini™



Quick Start Guide

1 Charge the Battery



Place the rechargeable battery into the charger, and plug the charger into the wall. The charge indicator light will turn RED when charging and GREEN when fully charged.

2 Install the Battery



Select the desired color light. Remove the flashlight button. Install battery positive end first. Reinstall flashlight button, OR install the threaded bow end cap.

3 Install on Rifle or Bow



Use as a flashlight, attach to bow stabilizer receiver, attach to bow stabilizer, or attach to rifle scope. Use the Quiet Momentary/On Off Button to activate the light, or plug in the wired remote pressure switch.

Charging the Battery

The Piglet Mini™ is designed to operate on a single Lithium Rechargeable Battery (included), a single AA size alkaline battery, or a single AA NiMH rechargeable battery. The lithium battery is preferred, and it will shine brighter and power the light for a longer period of time than the alkaline or NiMH batteries.

To charge the Lithium Battery included with the light, place the Lithium battery into the charger. Unfold wall adapter on the back of the charger, and plug the unit into the wall outlet. The light on the charger will shine red when the battery is charging, and it will turn green when the battery is fully charged. When the battery is fully charged, remove the battery from the charger, and remove the charger from the wall. Do not leave the charger unattended.



CAUTION: Do not charge Alkaline or NiMH batteries in the Lithium battery charger! Batteries of different chemistries may explode if placed in the Lithium battery charger. The voltage and charging pattern of the Lithium battery charger is not compatible with non-Lithium batteries, even batteries that are the same size.

Installing the Battery

To install the battery, unscrew the flashlight button. Insert the battery with the positive end first towards the head of the light. Reinstall the flashlight button, OR replace the flashlight button with the Threaded Bow Mount with Protective Cap.



Operating the Piglet Mini™ Light

Using the Flashlight Button: Press the button in until it clicks and the light will remain on until the button is clicked again.

Using the Momentary Button on the Threaded Bow Mount with Protective Cap: Press the button in slightly to turn the light on. It will remain on as long as the button is being pressed. It will turn off when the button is released. Press the button in completely to turn the light on. It will remain on until the button is pressed completely again.




Using the Wired Pressure Switch: Remove the weatherproof cover on the side of the Threaded Bow

Mount, and plug in the wired pressure switch. Attach the wired pressure switch to the bow riser or rifle stock using the double-sided hook and loop fastener. Apply pressure to the pad to turn on the light, and release pressure on the pad to turn the light off.




Adjusting the Beam: To make the beam narrow, slide the head of the light outward. To widen the beam, slide the head of the light inward.



Which Color Is Best:

- Green: Use the green color for most varmints and hogs. It is an easy color for most people to see while still being very difficult for the animals to detect.
- Red: Most animals do not have the ability to see the color red. Use the red color option for the most stealth. Red is also a great option if you have trouble spooking the animals with other colors of light. Red light also gives the most amount of eye reflection.
- White: The white color is the brightest option. Use the white color when the most amount of visibility is needed.



Mounting the Piglet Mini™ Light

Using the Rapid Scope Mount™: Unscrew the center thumb screw enough to fit around the light on one side and rifle scope on the other side. Tighten the thumb screw to secure in place. This may also be used to attach the light to large barrels (1" or larger), bow stabilizers, or any other parallel tubing (1"-1.25").



Using the Threaded Bow Mount With Protective Cap: After removing the flashlight button and replacing it with the Threaded Bow Mount, remove the threaded cap to reveal the threaded portion of the

mount. Then screw the light into the stabilizer insert on the bow riser. The light may be activated using the push-button on the side of the light or by installing the wired pressure switch.



Other Mounting Options Available:

- The 90° Rapid Scope Mount™ will attach the light to perpendicular tubes on roll bars or bumpers, camera tripod legs, and bicycle handle bars.
- The Universal Shotgun Mount is available in both parallel and perpendicular models. The light will attach to one side of the flexible mount and the other end will fit around objects up to three inches in diameter.
- The Piglet Mini™ will also fit into various ring mounts that attach to any picatinny rail system.



Piglet Mini™ Warranty Registration

Date of Purchase

Name

Address

City, State, Zip

Phone

E-mail

Name of store where purchased

Received as a gift or Purchased for yourself

Please rate your level of satisfaction with this product from 1-10 with 10 being most satisfied. If you have yet to use this product, please circle N/A. Please circle one.

1 2 3 4 5 6 7 8 9 10 N/A

Elusive Wildlife Technologies, LP respects your privacy and we will not sell or provide your personal information to any other party. However, we would like to occasionally send you information about your Elusive Wildlife product or special offers. If you do not wish to receive this information please check here .

Please mail or e-mail warranty info to:
Elusive Wildlife Technologies, LP
 1107 West Dallas Street, Suite A
 Conroe, TX 77301
 800-780-6861
 email: info@elusivewildlife.com