

The Kill Light®

Pro 3 Color Head Lamp


Thank you for purchasing the Kill Light® Pro 3 Color Head Lamp from Elusive Wildlife Technologies, LP. Hunting or viewing wildlife after sunset is extremely exciting, yet very challenging. If you have not already done so, please check your local game laws to ensure it is legal to use an artificial light source while hunting or observing animals at night. Elusive Wildlife Technologies, LP and its affiliates do not condone or promote the use of

any of our products as a means to illegally harvest any animal. Please take a moment to read these instructions thoroughly before initial use. Also, reading the included helpful tips will ensure you get the most out of your head lamp and ensure your warranty remains in effect for the full 12 month period.


Pro 3 Color
Head Lamp
GREEN RED WHITE



Place the 18650 or the 21700 batteries into the battery compartment.




Unplug the Quick Detach Power Plug connected to the battery compartment.




Connect the battery compartment using the Quick Detach Power Plug to the to the Wall Charger.




When plugged into the wall, the Wall Charger will shine red when charging, and green when charging is complete.



Rotating the head of the light will adjust the beam width.



Pressing the top 3-Color button will change the color of the light. The light will only change colors while it is turned on.



Rotating the head of the light will adjust the beam width.

Operating the Pro 3 Color Head Lamp

Expected Runtime Using EWT Tru-Max™ Batteries

The Pro 3 Color Head Lamp is designed to run on one or two batteries. The light is the same brightness using either one or two batteries. Operating on two batteries increases the runtime over using only one battery. When the batteries are getting low, the light will flash off and back on to indicate there is about 30 minutes of power left before the batteries are dead.

EWT 21700 5000mAh Tru-Max™ batteries, runtime is 14 hours using two batteries, or 7 hours using a single battery.

EWT 18650 3500mAh Tru-Max™ Platinum Series batteries, runtime is 8 hours using two batteries, or 5 hours using a single battery.

EWT 18650 2600mAh Tru-Max™ batteries, runtime is 5 hours using two batteries, or 3 hours using a single battery.

Charging The Batteries

To charge the batteries in the head lamp, first install the batteries in the head lamp Battery Compartment. Then unplug the Quick Detach Power Plug connected to the battery compartment. Then connect the battery compartment using the Quick Detach Power Plug to the Wall Charger. When plugged into the wall, the Wall Charger will shine red when charging, and green when charging is complete. The Wall Charger may take up to 7 hours to charge the 18650 batteries and up to 10 hours to charge the 21700 batteries. Charging times will vary depending on the capacity and the current charge level of the batteries. If it takes longer than 12 hours to charge, disconnect the Wall Charger and reconnect the head lamp and Battery Compartment. You may use the head lamp as usual until it needs charging again. Occasionally, some batteries will need a few charge cycles to show a full charge on the Wall Charger. This is a normal battery break-in period.



Using the 18650 Batteries with the 21700 Battery Adapter

If using 18650 batteries with the head lamps, it is best to use the 18650 to 21700 battery adapter. Simply place the 18650 battery into the adapter positive end first, and then place the adapter, with the 18650 battery, into the battery compartment.



Installing the Batteries

To install the batteries, place the 18650 (with adapter) or the 21700 batteries into the battery compartment. Both batteries face the same direction, matching the positive (+) and negative (-) on the light with the positive (+) and negative (-) on the battery compartment. The Pro 3 Color Head Lamp will operate on a single battery or two batteries.




Turning the Head Lamp ON/OFF

Pressing the side button will turn the head lamp on and off.

Adjusting the Brightness of the Head Lamp

Twisting the side knob on the Pro 3 Color Head Lamp will adjust the brightness.




Adjusting the Beam Width

To adjust the beam width, rotate the head of the light clockwise to make the beam wider, and counter-clockwise to make the beam narrower.

Changing Color of the Head Lamp

The Pro 3 Color Head Lamp has the ability to change the color of the light with the press of the Color Selector Button located on the top of the light. Pressing the Color Selector Button will cycle through three different colors: white, green, and red. No need to cycle through each color every time it is turned on. The light will remain the same color when it is switched off and on. The color will only change by pressing the Color Selector Button when the light is on.



Disconnecting The Power

The Pro 3 Color Head Lamp is equipped with a Quick Detach Power plug connected to the battery compartment. This is useful to prevent the head lamp from turning on accidentally in a gear bag or backpack.



Warranty

Elusive Wildlife Technologies, LP warranties this product for a period of 1 year from original date of purchase. This warranty covers manufacturer defects as well as malfunction during normal operation. Please complete the warranty registration and mail in along with proof of purchase to register your light. You may also e-mail your registration and proof of purchase to info@elusivewildlife.com.

Elusive Wildlife Technologies, LP will not warranty any light damaged by user neglect or failure to adhere to these instructions and guidelines. No lights will be warranted due to water penetration, animal damage, or theft.

Pro 3 Color Head Lamp

Date of Purchase _____

Name _____

Address _____

City, State, Zip _____

Phone _____

E-mail _____

Name of store where purchased _____

Received as a gift or Purchased for yourself

Please rate your level of satisfaction with this product from 1-10 with 10 being most satisfied. If you have yet to use this product, please circle N/A. Please circle one.

1 2 3 4 5 6 7 8 9 10 N/A

Elusive Wildlife Technologies, LP respects your privacy and we will not sell or provide your personal information to any other party. However, we would like to occasionally send you information about your Elusive Wildlife product or special offers. If you do not wish to receive this information please check here .

Please mail or e-mail warranty info to:
Elusive Wildlife Technologies, LP
 1107 West Dallas Street, Suite A • Conroe, TX 77301
 800-780-6861 email: info@elusivewildlife.com